


1. Fastening nut M6





2. Setscrew M6



3. Hook  
 LobbyWall 600 (570) – 3 hooks  
 LobbyWall 800 (770) – 5 hooks  
 LobbyWall 1000 (970) – 6 hooks  
 LobbyWall 1200 (1170) – 7 hooks

*Fasten the metal hooks with two thread forming screws.*



*Position the hooks on the back.*